

Fitting of the Mocad Seat Attachment

1. Remove all packaging. Check that there are three separate pieces to the seat attachment.
2. Fit the bracket, which will hold the seat, to the left hand side of the trolley. *Fig 1*
 - * This bracket fits to the outside frame and rests on the bar running parallel from the controller.
(Black box at the front of the battery tray.)
3. Tighten this bracket with the holding screw to fix the bracket securely in position.
4. The spring-loaded bar fits into this bracket. *Fig 2*
5. Now fit the seat on to this spring-loaded bar.



Fig 1 Fit bracket here.