

Fitting of the Mocad Umbrella holder

1. Remove the two rubber plugs from the right hand side of the handle of your Mocad Electric Golf Trolley.
2. Once these plugs have been removed attach the handle so it sits over the holes left from the removal of the rubber plugs.
3. Slide the two screws through the holder and into the handle.
4. Insert the nut into the back of the handle and hold in place.
5. With a Philips screwdriver tighten the screw so it catches the nut at the base of the handle.
6. Repeat with second screw and nut.

(NOTE: Never leave the umbrella un-attended while still in the holder)

