

Replacing Controller

To replace the Controller on your Mocad please follow the instructions attached and if you have any queries please do not hesitate to contact our service departments, contact details are in your Owners Manual

Tools required to replace the Controller

Philips Head Screw Driver

Step 1 Remove Old Controller

- The controller box is a black box located behind the battery tray.
- Disconnect the lead from the controller which is connected to the motor
- Disconnect the lead from the controller which is connected to the switch
- Take your Philips head screw driver and remove the 4 screws holding the controller in place. Remove the controller

Step 2 Fit new Controller

- Heat shrink will be supplied. Please ensure that you put the Heat shrink on both the lead from the motor and the switch
- Once Heat shrink is attached, take new controller and reattach the lead from the controller to the lead on the motor
- Reattach the lead from the controller to the switch
- Place the controller back onto the trolley and with the 4 screws, please tighten back on.